

# Configuring Traktor Pro 2 for the DJControl Instinct (OS X version)

(Updated: October 2014 for version 2.68)

## *1- Console configuration*

From the DJ Console control panel, go to the **ADVANCED** tab and make sure the following parameters are set correctly:


### **a) MIDI channel** is set to **1 (Defaults)**.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the profile accordingly. Consult Traktor's user manual for more details.

### **b) Headphone channels** is set to **3-4 (default)**

### **c) Pitch**


- Pitch repeat frequency: **30 ms**
- Pitch repeat delay: **0 ms**



## 2- Audio configuration in Traktor Pro 2


a) From the main menu, click on **PREFERENCES**, and select **AUDIO SETUP**.

Choose **Hercules DJControl Instinct** as **Audio Device**. You can also adjust the LATENCY.



b) Under **Output Routing**,

- Under **Mixing Mode**, select **Internal**.
- Set **Output 3 & 4** for **Monitor** and **Output 1 & 2** for **Master**.



### 3- Configuration of the Midi controllers in Traktor Pro 2 (Version 2.68)

a) At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



b) A menu will then display the different categories that will be imported.



c) In **Controller-Manager**:

- For **Device**, select - **DJ Instinct - Generic MIDI**
- Select **DJControl Instinct** for both **In-Port** and **Out-Port**.



**This menu also give you access to the various MIDI settings, should you wish to modify them.**  
(Consult chapter **13.21 – Controller Manager** of the user manual for more details).



## **MIDI Layout for the DJControl Instinct and Traktor Pro 2**

**NOTE:** The terms used are those employed in Traktor.

### Main Configuration:

#### **1- Tempo Adjust**



#### **2- Tempo Bend (Down/Up)**

#### **3- Sync On**

#### **4- Seek position (Backward/Forward)**

#### **5- EQ (Bass/Mid/Treble)**

#### **6- Monitor Cue On**

#### **7- Load Selected**

#### **8- Tempo Bend (stepless)**



#### **9- Jog Touch/Jog Turn/Scratch**

#### **10- Volume Fader**


#### **11- Cue**

#### **12- Deck Play**








#### **13- X-Fader**







## Navigation/ browser:




## Folder Navigation


-  : Open Browser toggle
-  +  : Step Browsing
-  +  : Expand/Collapse
-  +  : Fast Browsing

## Playlist navigation (Default)

-  : Open Browser toggle
-  : Step browsing
-  +  : Fast Browsing




## Hot Cue



- **1:** Select / Set+Store Hotcue 1
- **2:** Select / Set+Store Hotcue 2
- **3:** Select / Set+Store Hotcue 3
- **4:** Select / Set+Store Hotcue 4
- **Vinyl** + **1/2/3/4:** Delete Hotcue



## Loop



- **1:** Loop Set (In/Out)
- **2:** Key Lock
- **3:** Loop Size Selector (-)
- **4:** Loop Size Selector (+)
- **Vinyl** + **1/2/3/4:** Slot Capture from Deck  
(See [Samples](#))



## Effect



- **1:** Effect 1 On/Off
- **2:** Effect 2 On/Off
- **3:** Effect 3 On/Off
- **-1/2/3 + PITCH:** Effect 1/2/3 amount
- **4 + PITCH:** Dry/Wet Group



Vinyl +  : Filter On/ Adjust (Deck A)

Vinyl +  : Filter On/ Adjust (Deck B)


Vinyl +  : Effect Unit 1 On/Off (Deck A & Deck C)

Vinyl +  : Effect Unit 2 On/Off (Deck B & Deck D)



## Sample

**Vinyl** +  : Deck Play/Pause



- **1**: Slot 1 Play
- **2**: Slot 2 Play
- **3**: Slot 3 Play
- **3**: Slot 4 Play



**Vinyl** + **1/2/3/4**: Slot Play mode (One Shot/ Looped)





## Midi Controllers/Notes map



