

# Configuring Traktor 2 Pro for DJControl Jogvision (OS X version)

(Created: September 2015 for version 2.90)

## **1- Control panel configuration**

First , open the **DJ control panel** and configure the following parameters


- a) Under **Controls-Audio**;
  - **Headphone channels** are set to **3-4(Default)**;
  - **MIDI Resolution** should be set to **Extended (14-BIT) (Default)**.
  
- b) Next, set the **In-Jog Display** options according to your preferences.



## 2- Audio configuration in Traktor


- a) From the main menu, click on **PREFERENCES**, and select **AUDIO SETUP**.

Choose **DJControl Jogvision** as **Audio Device**.



You can also adjust the **Sample rate** and audio **LATENCY** if needed.

- b) Under **Output Routing**, set **Output 3 & 4** for **Monitor** and **Output 1 & 2** for **Master**.



### 3- Configuration of the Midi controllers in Traktor 2 Pro (Version 2.80)

a) At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.




b) A menu will then display the different categories that will be imported (Image may not reflect the actual Categories)

c) In **Controller-Manager**:

-Under **Device**, choose **HDJC Jogvision**;

- For both **In-Port** and **Out-Port**, be sure **DJControl Jogvision** is selected.



This menu also give you access to the various MIDI settings, should you wish to modify them. Refer to **Traktor User** manual (chapter **Controller Manager**) for more details.





## **MIDI Layout for the DJControl Jogvision and Traktor 2 Pro**

**NOTE:** The terms used are those employed in Traktor, unless otherwise indicated (\*)

### Main Configuration:


- A-** Tempo Adjust
- B-** KeyLock On  
*+SHIFT= Flux Mode On*
- C-** AIR FX On\* - Filter Adjust (Low pass)
- D-** Jog Turn (Tempo bend)
- E-** Jog Touch/ Scratch
- F-** EQ (Bass/ Mid/ Treble)
- G-** Monitor Cue On
- H-** Volume Adjust
- I-** Scratch On/Off\*
- J-** Mic On/Off\*
- K-** Only Browser On
- L-** Add as Next to Preparation List  
*+SHIFT= Favorite (Preparation List)*
- M-** Sync  
*+SHIFT= Sync (Deck C/D)*
- N-** CUE  
*+SHIFT= Cue Play*
- O-** Play/Pause  
*+SHIFT= Seek Position (Reset)*
- P-** Position (*X-Fader\**)



Monitor Cue / Monitor Mix




## Navigation/ browser:



Push down the **Browser** knob to switch between **Folders** and **Files**:


### Folder navigation



- **Select Up/Down** (Browser.Tree)  
*+SHIFT= Deck Gain*

- **Expand/Collapse**

### Playlist navigation(Default)



- **Select Up/Down** (Browser.List)  
*+SHIFT= Deck Gain*

- **Load Selected** (Deck A & B)



## Loop/ Freeze mode:

**Encoder:** Loop Size Selector (*Single and Multi FX mode*)

**Loop X 1/2:** Loop Size Selector /2



**Loop On:** Loop Set

**+SHIFT= Freeze Mode On** / Freeze Slice count Adjust (4x)

**Loop X 2:** Loop Size Selector x2



**Pad 1-4 :** Slice Trigger 1-4



## FX (Unit 1-2):

**FX1:** Effect 1 On

**SHIFT+FX1:** Effect 1 Select

**FX2:** Effect 2 On

**SHIFT+FX2:** Effect 2 Select

**FX3:** Effect 3 On

**SHIFT+FX3:** Effect 3 Select


**SHIFT+Multi FX:** Effect Unit 1/2 On

**Encoder (Single mode):** Effect 3 Adjust

**SHIFT + Encoder:** Dry/Wet Adjust (Effect Unit 1-2)

**Encoder (Multi mode):** Effect 1/2/3 Adjust

**SHIFT + Encoder:** Dry/Wet Adjust (Effect Unit 1-2)



## Hot Cues



**Pad 1-4:** Select Set/Store Hot Cue 1-4

**SHIFT+Pad 1-4:** Delete HotCue 1-4




**Pad 1-4:** Select Set/Store Hot Cue 5-8

**SHIFT+Pad 1-4:** Delete HotCue 5-8


## Samples

**Pad 1-4:** Slot capture/Trigger/Mute

**SHIFT+ Pad 1-4:** Slot Stop/Delete/Load from list



## Midi controllers map



## Loop mode




## FX mode



## CUE 1-4



## Samples



## CUE 5-8



## Sample Bank

