

Configuring Traktor 2 for the DJControlWave (Windows version)


(Created: April 2014 for version 2.68)

1- Configuration of the MIDI channel

From the DJ Console control panel, make sure that **MIDI channel for controls** is set to **1**.

This is very important as the profile provided is configured for the DJControlWave to work on this channel.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the profile accordingly. Consult Traktor's user manual for more details.



2- Audio configuration in Traktor

As the DJControlWave is only a MIDI controller, you will need to configure Traktor's audio setup in order to use your sound card for playback and monitoring on separate stereo channels (Consult the user manual for more details).




3- Configuration of the Midi controllers in Traktor Pro 2 (Version 2.68)

- a. At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



- b. A menu will then display the different categories that will be imported (Image may not reflect the actual Categories)



- c. In **Controller-Manager**:

-For Device, select **DJControlWave - Generic MIDI**

- Do the same for both **In-Port** and **Out-Port**.

This menu also give you access to the various **MIDI** settings, should you wish to modify them.



MIDI Layout for the DJControlWave and Traktor Pro 2


NOTE: The terms used are those employed in Traktor, unless otherwise indicated (*)

Main Configuration:

- A-** Master Volume
- B-** Loop Active On (*Button**)
Loop Size Selector (*Encoder**)
- C-** Tempo Adjust
- D-** EQ (Bass/ Mid/ Treble)
- E-** Volume Fader
- F-** Jog Turn
- G-** Jog Touch / Scratch
- H-** Position (*X-Fader**)
- I-** Sync
- J-** Cue
- K-** Play/Pause



Navigation/ browser:



Folder navigation

Advanced (L) + Left Encoder: *Step browsing**

Advanced (L) + Left Encoder Button: Expand/Collapse


Playlist navigation

Advanced (L) + Right Encoder: *Step browsing**

Advanced (L) + Play/Pause: Load Selected



Headphone:



Advanced (R) +Left Encoder: Monitor Mix

Advanced (R) +Left Encoder Button: Monitor Cue On (Deck A)



Advanced (R) +Right Encoder: Monitor Volume

Advanced (R) +Left Encoder Button: Monitor Cue On (Deck B)



FX/ Filter:



1: Effect 1 On

2: Effect 2 On

3: Effect 3 On

1 + EQ High: Effect 1 Adjust

2 + EQ Med: Effect 2 Adjust

3 + EQ Low: Effect 3 Adjust

FX + Encoder: Dry/Wet Adjust

FX + Jog: Filter On / Filter Adjust



Hot Cue:

1: HotCue 1

2: HotCue 2

3: HotCue 3

↓ + **1/2/3:** Delete HotCue

Samples:

1: Slot 1 Capture/Trigger/Mute

2: Slot 2 Capture/Trigger/Mute

3: Slot 3 Capture/Trigger/Mute

SAMPLE + 1/ 2/ 3: Slot Stop/Delete/Load from List



Midi controllers map

