


A. Djay Pro Settings

This mapping is for djay Pro (tested in djay Pro release 1.3.1 in Mac OS 10.11 & 10.12)

1. Install the MIDI map in djay Pro

- Download DJ-4Set map file from Hercules support website, in the MIDI mapping area
<https://support.hercules.com/en/product/dj4set-en/>
- Uncompress it to get the .xml file, copy the xml file on Mac OS desktop
- Double click on it: djay Pro asks "Do you want to install the MIDI configuration "Hercules DJ 4Set"?". Click OK, the xml is installed in djay Pro and removed from the desktop.



2. Set the audio in djay Pro

- Connect your DJ 4Set to the Mac.
- Run djay Pro: it detects DJ 4Set.
- If djay Pro suggest this audio setup: Hercules DJ 4Set Audio Setup

"Please select the audio channels you want to use from this device:", then check:


Main Output

Pre-Cueing

Microphone"

And click on "OK".

- If you get no suggestion as audio setting, click on djay Pro > Preferences > Devices, and set:
Mixer Mode: Internal
Main Output: Hercules DJ 4Set ch 1-2
Pre-Cueing: Hercules DJ 4Set ch 3-4
Microphone: Hercules DJ 4Set
And click on "Apply".



3. Check the MIDI configuration

On djay Pro top bar, click on MIDI > Configure DJ 4Set Port 1....

Make sure the MIDI Configuration is Hercules DJ 4Set instead of Hercules DJ 4Set (built-in) to activate your new setting instead of the setting originally included in djay Pro.

B. djay Pro Graphic User Interface

djay Pro has a 2-deck and a 4-deck mode; you chose it with an icon on right of the top bar:

- 2-deck: click on the circle icon



- 4-deck: click on the 4 vertical bars.




1. 2-deck user interface

With 2-deck GUI (Graphics User Interface), you use just DJ 4Set deck A = deck 1 and deck B = deck 2.




2. 4-deck user interface

In 4-deck mode, you use the 4 decks of DJ 4Set: deck A = deck 1, deck B = deck 2, deck C = deck 3, and deck D.




C. DJ 4Set controls with dJAY Pro




Area	Key	Control	Action
1. Track Transport			
1	a	Play/Pause	Play / Pause the playback
	b	Cue	Sets a cue point / Go to Cue Point
	c	Sync	Set at the same speed as the track on the other deck
	d	Rewind/Fast Forward	Move Fast backward/forward
2. Jog Wheels			
2	a	Jog wheel	Rotation without pressure: Pitch bend Rotation with pressure: Scratch when Scratch mode is on
	b	Scratch On/Off	Set the jog wheels in vinyl mode (for scratch)

DJ4Set In djay PRO

Version 2.0




Area	Key	Control	Action
3. Pitch controls			
3	a	Pitch fader	Set the playback speed: on top = slower / on bottom = faster
	b	Pitch bend +/-	Change the speed temporarily / Release key = restore the speed
4. Browser controls			
4	a	Up / Down	Browse in the track list or in the folders list
	b	Folder	Browse in folder area - Select History, Explore, Playlist, Spotify...
	c	Load on Left	Load track on active left deck (Deck 1 or Deck 3)
	d	Load on Right	Load track on active right deck (Deck 2 or Deck 4)
	e	Files	Move the browser to the tracks list



Area	Key	Control	Function
5. Mixer controls			
5	a	Microphone volume	Set the microphone volume
	b	Mic On/Off	Switch the microphone on or off
	c	Equalization (treble, medium, bass)	Set the treble, medium or bass frequencies of the deck
	d	Vol. main	Master volume
	e	Cue-Mix	Choose headphones contents: cue = preview / mix = master
	f	Headphones volume	Set the headphones volume
	g	Cue Select	Select the deck you hear in the headphones in cue mode
	h	Volume fader	Set the volume of the deck
	i	Cross fader	Mix the sound from left and right

DJ4Set In djay PRO

Version 2.0



Area	Key	Control	Function
6. Deck controls			
6	a	Deck display	Show active decks: A(1) or C(3) on left, B(2) or (D) on right
	b	Modulate	Loop half / Loop double
	c	Deck C & D	Switch controls on next deck : A(1)<->C(3) / B(2)<->C(4)
	d	Shift	Change keys 1, 2, 3 into 4, 5, 6
	e	Keys 1, 2, 3...6	Key 1 = Auto Loop Key 2= Loop In Key 3= Loop Out Key 4 = Fx 1 Key 5 = Fx2 Key 6 = Censor (Reverse playback)