


# Configuring Traktor 3 for the DJ Console Mk2 (OS X version)

## 1- Audio configuration in Traktor

a) From the main menu, click on **PREFERENCES**, and select **AUDIO SETUP**

b) In **Soundcard**, select **Hercules DJ Console Mk2 Aggregate** as **Audio Device**. You can also adjust the AUDIO LATENCY.



c) Under **Output Routing**, set Output 3 & 4 for **Monitor** and Output 1 & 2 for **Master**




d) If you are using external sources, in **Input Routing**, select the DJ Console inputs for channels A&B.




## 2- Configuration of the Midi controllers in Traktor

- a. Expand **Hotkey and MIDI setup** and select **MIDI Interface**. Make sure **Hercules DJ Console Mk2 Port 1** is marked with an **X** in the ACTIVE column for both MIDI IN and OUT.



- b. From **MIDI Setup**, click the **Load** button. Locate and select the TKS file, then press OK



- c. Traktor is now configured to use the DJ Console Rmx.

## **MIDI Layout for the DJ Console Mk2 and Traktor3**

**NOTE:** The terms used are those employed in Traktor

### Main Configuration:

A- **Secondary Functions (See below)**

B- Deck Tempo

C- EQ (Bass/ Mid/ Treble)

D- Deck Loop – Loop Active/Out

E- Browser List Select Up/Down

F- Deck Time Stretch ON

G- Deck Volume

H-Deck Pitch Bend

I- Deck Load Selected

J- Deck Tempo - Sync

K- Deck Seek Position

L- Deck load Previous / Next

M- Deck Cue/Pause

N- Deck Play/Pause

O- X-Fader


P- Headphone:

- Deck Monitor Cue (Deck A)

- Deck Monitor Cue (Deck B)


- Mix

- Split



Secondary functions:

Press and hold the button "1" to access the effects (FX) functions:



A- Master Effect Knob 1

B- Master Effect Knob 3


C- Master Effect button 1

D- Master Effect button 4

E- Master Effect Previous /Next

F- Master Effect Knob 4

Press and hold the button "2" to access additional controls:



A- Deck Gain (A)

B- Deck Gain (B)

C- Browser Tree Select  
Up/Down/Expand/Collapse

D- Monitor Mix

E- Monitor Volume

F- Deck Cue Set (A)

G- Deck Cue Set (B)

Press and hold the button "3" to enable the Scratch function on the jog wheel.



## Midi controllers map

