

Configuring Traktor 3 for the DJ Console Mk2 (Windows version)

1- Configuration of the ASIO driver

- a) From the DJ Console control panel, set the audio mode to **ASIO**
- b) Click the **ASIO** tab and configure the various driver settings to be used by Traktor.

NOTE: These settings cannot be modified once Traktor has been launched.



2- Audio configuration in Traktor

a) From the **FILE** menu, select **AUDIO SETUP**


b) In **Soundcard**, select **Hercules DJ Console MK2 ASIO** as **Audio Device**. Notice that the **SAMPLE RATE** and **AUDIO LATENCY** should reflect the configuration previously made in the Control panel



c) Under **Output Routing**, set Output 3 & 4 for **Monitor** and Output 1 & 2 for **Master**




d) If you are using external sources, in **Input Routing**, select the DJ Console inputs for channels A&B.




3- Configuration of the Midi controllers in Traktor

- a. Expand **Hotkey and MIDI setup** and select **MIDI Interface**. Make sure **Hercules DJ Console Mk2 MIDI** is marked with an **X** in the ACTIVE column for both MIDI IN and OUT.



- b. From **MIDI Setup**, click the **Load** button. Locate and select the TKS file, then press OK



- c. Traktor is now configured to use the DJ Console Rmx.


MIDI Layout for the DJ Console Mk2 and Traktor3

NOTE: The terms used are those employed in Traktor

Main Configuration:


- A- **Secondary Function (See below)**
- B- Deck Tempo
- C- EQ (Bass/ Mid/ Treble)
- D- Deck Loop – Loop Active/Out
- E- Browser List Select Up/Down
- F- Deck Time Stretch ON
- G- Deck Volume
- H-Deck Pitch Bend
- I- Deck Load Selected
- J- Deck Tempo - Sync
- K- Deck Seek Position
- L- Deck load Previous / Next
- M- Deck Cue/Pause
- N- Deck Play/Pause
- O- X-Fader
- P- Headphone:

- Deck Monitor Cue (Deck A)
- Deck Monitor Cue (Deck B)
- Mix
- Split



Secondary functions:

Press and hold the button "1" to access the effects (FX) functions:



A- Master Effect Knob 1

B- Master Effect Knob 3


C- Master Effect button 1

D- Master Effect button 4

E- Master Effect Previous /Next

F- Master Effect Knob 4

Press and hold the button "2" to access additional controls:



A- Deck Gain (A)

B- Deck Gain (B)

C- Browser Tree Select
Up/Down/Expand/Collapse

D- Monitor Mix

E- Monitor Volume

F- Deck Cue Set (A)

G- Deck Cue Set (B)

Press and hold the button "3" to enable the Scratch function on the jog wheel.



Midi controllers map

