


Configuring Traktor 2 Pro for the DJ Console Rmx (Windows version)

(Updated: Mars 2014 for version 2.68)

1- Configuration of the ASIO driver/ MIDI channel



a) From the **DJ Console control panel**, set the audio mode to **ASIO**

b) Click the **ASIO** tab and configure the various driver settings to be used by Traktor.

NOTE: These settings cannot be modified once Traktor has been launched.

c) Next, go to the **ADVANCED** tab, and make sure that MIDI channel is set to **1**.


This is very important as the profile provided is configured for the DJ Console Rmx to work on this channel.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the profile accordingly. Consult Traktor's user manual for more details.




2- Audio configuration in Traktor


a) From the **FILE** menu, select **Audio Setup**. Choose **Hercules DJ Console Rmx ASIO** as **Audio Device**. Notice that the SAMPLE RATE and AUDIO LATENCY should reflect the configuration previously made in the Control panel



b) Under **Output Routing**, set Output 3 & 4 for **Monitor** and Output 1 & 2 for **Master**




c) If you are using external sources, for **Input Routing**, select the DJ Console inputs for Input Deck A&B.



Don't forget to select the appropriate source Input type in the **DJ Console control panel**.

You can switch between internal (**Track Deck**) and external (**Live Input**) playback by selecting the appropriate mode for the desired deck:




3- Configuration of the Midi controllers in Traktor 2 Pro (Version 2.68)

a. At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



b. A menu will then display the different categories that will be imported (Image may not reflect the actual Categories)



c. In **Controller-Manager**:

-For Device, select **DJ Console Rmx - Generic MIDI**

- Do the same for both **In-Port** and **Out-Port**.

This menu also give you access to the various MIDI settings, should you wish to modify them.



MIDI Layout for the DJ Console Rmx and Traktor 2 Pro


NOTE: The terms used are those employed in Traktor, unless otherwise indicated (*)

Main Configuration:

- A-** *SHIFT (See **FX Mode**)
- B-** Deck Gain
- C-** EQ (Bass/ Mid/ Treble) and EQ Kill
- D-** *Scratch On/Off
- E-** Tempo bend -
- F-** Tempo bend +
- G-** Loop:
 - 1: Loop Size -Previous
 - 2: Loop Set
 - 3: Loop Size -Next
- H-** Cues
 - 4: Previous Cue/Loop
 - 5: Cue Set /Store
 - 6: Next Cue/Loop
- I-** Tempo
- J-** Seek position
- K-** Monitor Cue
- L-** Load Selected
- M-** Sync
- N-** Jog Turn
- O-** Volume fader
- P-** Master Volume
- Q-** Cue
- R-** Seek position: (***Stop** – return to start)
- S-** Play/Pause
- T-** X-Fader



FX Mode (**SOURCE** button ON):



1- Effect 1 On **4-** Effect 1 select

Treble: Effect 1 amount

2- Effect 2 On **5-** Effect 2 Select

Medium: Effect 2 amount

3- Effect 2 On **6-** Effect 2 Select


Bass: Effect 2 amount

Beat Lock: Filter On (Hold)

Balance: Filter Adjust

A- Effect Unit 1

B- Effect Unit 2




Scratch:



STOP + Jog Wheel : Jog Turn (Scratch)



Navigation/ browser:



Folder navigation

- **Left:** Open Browser toggle
- **Left + Up/Down:** Step browsing
- **Left + Right:** Expand/Collapse




- **Folder +** : Fast browsing

Playlist navigation (Default)

- **Up/Down** : Step browsing
- **Right:** Open Browser toggle



- **Right +** : Fast browsing



Midi controllers map

