

# Configuring Traktor 2 Pro for the DJ Console Rmx (OS X version)

(Updated: Mars 2014 for version 2.68)

## ***1- Configuration of the MIDI channel***

From the DJ Console control panel, go to the **ADVANCED** tab, and make sure that MIDI channel is set to **1**.

This is very important as the TSI profile provided is configured for the DJ Console Rmx to work on this channel.

If you have multiple MIDI controllers, or would like to use the DJ Console on a different MIDI channel, you will need to modify the TSI profile accordingly. Consult Traktor's user manual for more details.




## 2- Audio configuration in Traktor Pro

a) From the main menu, click on **PREFERENCES**, and select **AUDIO SETUP**. Choose **Hercules DJ Console Rmx** as **Audio Device**. You can also adjust the AUDIO LATENCY.



b) Under **Output Routing**, set Output 3 & 4 for **Monitor** and Output 1 & 2 for **Master**.



c) If you are using external sources, for **Input Routing**, select the DJ Console inputs for Input Deck A&B.



Don't forget to select the appropriate source Input type in the **DJ Console control panel**.

You can switch between internal (**Track Deck**) and external (**Live Input**) playback by selecting the appropriate mode for the desired deck:




### 3- Configuration of the Midi controllers in Traktor 2 Pro/Duo (Version 2.68)

a. At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



b. A menu will then display the different categories that will be imported (Image may not reflect the actual Categories)



c. In **Controller-Manager**:

-For Device, select **DJ Console Rmx - Generic MIDI**

- Do the same for both **In-Port** and **Out-Port**.

This menu also give you access to the various MIDI settings, should you wish to modify them.



## **MIDI Layout for the DJ Console Rmx and Traktor 2 Pro**


**NOTE:** The terms used are those employed in Traktor, unless otherwise indicated (\*)

### Main Configuration:

- A- \*SHIFT (See FX Mode)**
- B- Deck Gain**
- C- EQ (Bass/ Mid/ Treble) and EQ Kill**
- D- Scratch On/Off**
- E- Tempo bend -**
- F- Tempo bend +**
- G- Loop:**
  - 1: Loop Size -Previous
  - 2: Loop Set
  - 3: Loop Size -Next
- H- Cues**
  - 4: Previous Cue/Loop
  - 5: Cue Set /Store
  - 6: Next Cue/Loop
- I- Tempo**
- J- Seek position**
- K- Monitor Cue**
- L- Load Selected**
- M- Sync**
- N- Jog Turn**
- O- Volume fader**
- P- Master Volume**
- Q- Cue**
- R- Seek position: (\*Stop – return to start)**
- S- Play/Pause**
- T- X-Fader**



## FX Mode (**SOURCE** button ON):



**1-** Effect 1 On                      **4-** Effect 1 select

**Treble:** Effect 1 amount

**2-** Effect 2 On                      **5-** Effect 2 Select

**Medium:** Effect 2 amount

**3-** Effect 2 On                      **6-** Effect 2 Select


**Bass:** Effect 2 amount

**Beat Lock:** Filter On (Hold)

**Balance:** Filter Adjust

**A-** Effect Unit 1

**B-** Effect Unit 2






## Scratch:



**STOP + Jog Wheel : Jog Turn (Scratch**

## Navigation/ browser:



## Folder navigation

- **Left:** Open Browser toggle
- **Left + Up/Down:** Step browsing
- **Left + Right:** Expand/Collapse




- **Folder +** : Fast browsing

## Playlist navigation (Default)

- **Up/Down** : Step browsing
- **Right:** Open Browser toggle



- **Right +** : Fast browsing





## Midi controllers map

