



Router 802.11G-54

Firmware update



Contents:

- Firmware Version 3.0.14

Instructions to update your Modem Router:

1. Connect your computer to your Router using the included Ethernet cable (black). Warning: the update must not be carried out via a WiFi connection.
2. Make sure that no one is currently connected to your Router via WiFi, and that no one else is using your Router to surf the Internet.
3. Launch your **QuickAccess** application to access your Router's **WiFi Manager** interface.
4. Once you have entered your password ("**password**" by default), click the **Toolbox** button.
5. Next, click the **Update firmware** button, then **Browse...** and go to the folder containing the new firmware.
6. Select the file "**H-Router-802.11G-54-FW-V3.0.14.fmw**" and click the **OK** button, then the **Update** button.
7. Updating of your Router begins; this operation may take more than one minute to complete.
VERY IMPORTANT: MAKE ABSOLUTELY SURE NOT TO TURN OFF YOUR ROUTER OR YOUR COMPUTER DURING THIS PHASE!
8. Once the update is finished, your Router will automatically restart (the LEDs will flash several times) and will once again display the connection page to **WiFi Manager**.
9. You can now enter your password again and verify your firmware version by displaying the **Product Information** page.

Changes and improvements:

- Resolves the connection problem with a Nintendo DS or DS-Lite console.