

Virtual DJ Pro configuration for DJ Control Air

Installation procedure:

With Virtual DJ closed, copy the appropriate files in their respective locations:

Hercules DJControl Air mapping.xml:

PC -> **My Documents\VirtualDJ\Mappers**

MAC -> **Documents\VirtualDJ\Mappers**


Hercules DJControl Air definition.xml:

PC -> **My Documents\VirtualDJ\Devices**


MAC -> **Documents\VirtualDJ\Devices**

The DJ Control AIR should now be automatically recognized by Virtual DJ, and selectable in the MAPPER tab of the configuration menu:

PC




MAC



All that is left to do is to configure the audio section as follows:

PC



MAC



Your DJ Control can now be used with Virtual DJ.

Configuration de Virtual DJ Pro pour DJ Control Air

Procédure d'installation :

Avant de lancer Virtual DJ, copiez les fichiers dans leurs emplacements respectifs:

Hercules DJControl Air mapping.xml:

PC -> **Mes Documents\VirtualDJ\Mappers**

MAC -> **Documents\VirtualDJ\Mappers**


Hercules DJControl Air definition.xml:

PC -> **Mes Documents\VirtualDJ\Devices**


MAC -> **Documents\VirtualDJ\Devices**

La DJ Control AIR devrait maintenant être reconnu automatiquement par Virtual DJ, et apparaître sous l'onglet MAPPER du menu de configuration.

PC




MAC



Ne reste plus qu'à configurer la partie audio de la console comme ceci :

PC



MAC



Votre console peut maintenant être utilisée avec Virtual DJ.