


Configuring Traktor Pro/Duo for the DJ Console Mk2 (OS X version)


1- Audio configuration in Traktor

a) From the main menu, click on **PREFERENCES**, and select **AUDIO SETUP**. Choose **Hercules DJ Console Mk2** as **Audio Device**. You can also adjust the AUDIO LATENCY.



b) Under **Output Routing**, set Output 3 & 4 for **Monitor** and Output 1 & 2 for **Master**

OS X Snow Leopard (10.6)



OS X Tiger (10.4) / Leopard (10.5)



2- Configuration of the Midi controllers in Traktor Pro (Version 1.27)

a. At the bottom of the configuration menu, click the **Import** button to locate and select the **.TSI** configuration file.



b. **Controller Mapping, MIDI Device Setup** and **Effects Settings** should be selected before clicking OK



c. In **Controller-Manager:**

-For Device, select **Generic MIDI-DJ Console Mk2**

- Do the same for both **In-Port** and **Out-Port.**

This menu also give you access to the various MIDI settings, should you wish to modify them.




MIDI Layout for the DJ Console Mk2 and Traktor Pro/Duo

NOTE: The terms used are those employed in Traktor

Main Configuration:

- A- FX/Cue/Loop buttons/ **Secondary Function (See below)**
- B- Deck Tempo
- C- EQ (Bass/ Mid/ Treble)
- D- Toggle FX/Cue/Loop mode
- E- Browser List Select Up/Down
- F- Deck Time Stretch ON
- G- Deck Volume
- H-Deck Pitch Bend
- I- Deck Load Selected
- J- Deck Tempo - Sync
- K- Seek Position/ Scratch
- L- Deck load Previous / Next
- M- Deck Cue/Pause
- N- Deck Play/Pause
- O- X-Fader
- P- Headphone:

- Deck Monitor Cue (Deck A)
- Deck Monitor Cue (Deck B)
- Mix
- Split



Secondary functions:



- Press and hold the button **2** to control the deck's gain using the Pitch Knobs (A & B)



- Press and hold the button **3** to enable the Scratch function on the jog wheel.



FX mode:

- 1-** Effect 1 On
- 2-** Effect 2 On
- 3-** Effect 3 On



Cue mode:

- 1-** Select/ Set+Store Hotcue 1
- 2-** Select/ Set+Store Hotcue 2
- 3-** Select/ Set+Store Hotcue 3



Loop mode:

- 1-** Loop Size 1/2
- 2-** Loop Size 2
- 3-** Loop Size 4



Midi controllers map

