


Connection guide - XPS 2.140 / XPS 2.160

You will first notice that each satellite have a different connector. This is explained by the fact that one contains the controls as well as a stereo input and a headphone output:



Simply connect each connector to the appropriate socket on the back of the subwoofer:



Next, connect the input cable to the RED and WHITE input socket:



Finally, connect your source:

- 1- Using the minijack: For computers, portable CD or MP3 Players
- 2- Adding the minijack-to-RCA "Y" adapter for connecting game consoles or DVD players.

