

My computer always reboots automatically at Windows XP startup with my 3D Prophet 7500 128MB Dual Display board. How can I resolve this problem?

This problem may occur on some specific configuration under Windows XP. It happens just when Windows try to load your display drivers.

This problem has been resolved with the release of a new bios update, available in the [download section](#).