

My TV is properly connected to the graphic board and Hercules display control panel detects a TV connected but after turning on TV output to ON, TV receives no signal?

This problem occurs when the only VGA screen is plugged in the **second** graphic board VGA output (VGA connector located far from the motherboard). To solve this problem, simply turn your computer off, unplug VGA screen connector from graphic board VGA 2 connector and plug it in the VGA 1 connector (VGA 1 connector is located close to the motherboard). Then restart the computer and activate TV-out as describe through the Hercules graphic board user's manual.