

The “Auto-adjust” button does work in DVI mode, why ?

Size, position, frequency and phase notions are not applicable in DVI mode. Digital signal received by the Prophetview monitor make the display to automatically adjust itself to the screen size.

Then, it is normal that the “Auto-adjust” button has no action in DVI mode.

Some other functions are not applicable in DVI mode. The following functions are accessible in the OSD menu:

- Auto-adjust
- Predefined color temperature choice (Office, 6500K, 9300K).