

Can I use two 16/12 FW on the same computer?

For the moment, the driver can only handle one 16/12 FW per computer at a time.