

## My DJ Control MP3 is not working as a MIDI controller anymore.

In **Device Manager** > **SOUND VIDEO AND GAME CONTROLLERS**, you should normally get the following components after the installation:



If **Hercules DJ Control MP3** (here in blue) is recognized as another **USB Human Interface Device**, you will not be able to use the DJ Control as a MIDI controller. You will need to reinstall the driver

To prevent this problem, be sure to always connect your DJ Control to the same USB port it was installed on.