


## How can I connect my speakers to my game console or DVD player ?

The XPS 5.170 can be connected to a variety of device, and as such, comes with all necessary cables and adaptors.

To connect a game console or any another devices that only has a stereo output, the connection is fairly simple:


- You will only need to use 1 of the 1/8" mini jack cable, and one female 1/8"-to- Female RCA "Y" adapters (included with your system)



- Most devices (game console, DVD player, VCR) usually connect to the a TV using 3 cables, color-coded according to their use:

- YELLOW: Video
- RED: Audio (right)
- WHITE: Audio (left)

For this example, will use a game console (Playstation 2), configuration is the same for other devices.



Starting from your source (PS2), connections should be done as follow:

- The YELLOW cable stays connected to the TV to transmit the video signal (1)
- The RED and WHITE connectors are first attached the "Y" adaptor (2).
- The other end of the "Y" adaptor is connected to the 1/8" mini jack cable (3), which is then connected to the corresponding input (**FRONT**) on the back of the subwoofer (4).

**\*\*\*IMPORTANT\*\***: As indicated in the manual, be sure that NOT to connect the REAR and CEN/SUB cables to the back of the subwoofer, which would put the system in 5.1 mode, making only the 2 front speakers functional.