

Truncated display on an HDMI screen

When I connect my eCAFÉ™ to a screen using the HDMI connector, the display is truncated or incomplete.

Solution

You need to adjust the “Underscan” setting on your screen or TV set. Please refer to your screen or TV set’s user manual for more information.