

My eCAFÉ won't start up


My eCAFÉ won't start up.

When I press the ON/OFF button, the LED lights up for a few seconds, then goes dark.

Solution


The boot switch is in the "EXT" position, and the card reader contains no bootable SD card.

- Open the internal storage expansion slot's cover plate.



1


Hercules eCAFÉ™ Slim HD



1

Hercules eCAFÉ™ EX HD

- Set the switch to the “INT” position.



- Close the cover plate and start up your eCAFÉ.