

Configuring Traktor 2 for the DJ Console MK2



Setting up the ASIO driver

First, set the DJ Console MK2 mixer to ASIO mode by clicking **ASIO** in the **Audio Mode** section of the MK2 control panel. This mode must be enabled before starting the Traktor software.



Setting up audio in Traktor

- a. Go to Traktor's setup menu
- b. Under the **Audio** tab , make sure that **Hercules DJ Console Mk2 ASIO** is selected as the **Audio Device**.




- c. Next, configure the routing options in the **Channel Setup** section. Make sure that 3&4 are used for **Monitor** and 1&2 for **Master** out.


Setting up MIDI controllers in Traktor

- a. Go to Traktor's setup menu.
- b. Access the **Input** tab menu. Make sure that **Hercules DJ Console Mk2 MIDI** is selected in the **interface** section.
- c. Click the **Load** button in the **Settings** section.
- d. Locate and select the TKS file in order to load it.
- e. Click **OK**.

Traktor is now configured for use with DJ Console Mk2.



Traktor DJ Studio 2 – DJ Console Mk2 Control layout



- | | |
|------------------------------------|--|
| A : Deck EQ | I : List Select Up/Down |
| B : Deck Tempo Fine | J : Deck Tempo Sync |
| C : Deck Loop lengths | K : List Load Track DeckA/DeckB |
| D : Deck Loop Set/In | L : Deck Cue Set |
| E : Deck Volume | M : Deck Seek Position |
| F : Deck Pitch Bend Up/Down | N : Deck Play |
| G : Deck Key Join | O : X-Fader |
| H : Deck Tempo Sync Set | P : Monitor Cue DeckA/DeckB |

[The terms used in this document are those used in Traktor DJ Studio]

MIDI controllers map

